




YT-N9C 桌面摇头风扇 用户手册




感谢您选择ORICO!
在您使用本产品前,请仔细阅读这一份说明书。

简介

产品名称: USB桌面摇头风扇
产品型号: N9C
原材料: ABS/PP/电子元件

规格

产品尺寸: 140x115x229mm
输入: DC5V, 1A
电压: DC3.7V
充电时间: 约4小时




图例

- | | |
|---------|-----------|
| ① 风叶 | ⑤ 底座 |
| ② 前网罩 | ⑥ 工作指示灯 |
| ③ 充电指示灯 | ⑦ 摇头功能按键 |
| ④ 开关按钮 | ⑧ USB-C端口 |

使用指南

- 风扇连接电源或者充满电后,按下开关按钮第一次,为1档风;再按一次,切换到2档风;按第3次,切换到3档风。1档至3档,风力逐级加大,第3档为最大风力。
按第4次,关闭开关至关机状态。
开机状态下,按下摇头按键,风扇开始自动左右摇头,再按一次摇头按键,即关闭自动摇头功能。
- 风扇可以上下30度调节,如图一所示。
- 关于充电。
充电时,请使用5V电压的USB-C充电线进行充电。
充电过程中,充电指示灯红色常亮表示正在充电,充满电后充电指示灯变成绿色常亮。
温馨提示:为保证电池的使用寿命,风扇充满电后请及时关闭电源,停止充电。
- 工作过程中,工作指示灯蓝色常亮,切换档位时,相应档位的指示灯跟随切换。



保修条件

USB桌面摇头风扇在严格的质量控制和检验流程的条件下生产,质量可靠。自购买之日起,提供6个月的保修服务。

但以下人为和不可抗力因素所导致的故障,即使产品在保修期内,亦不能享受免费维修服务。


- 用户使用不当。
- 自然灾害或其他不可抗力因素。
- 经过其他非生产商指定的维修机构拆机或维修过。
- 震动冲击或存储条件不当。
- 其他非产品质量本身的因素所导致的故障。

警告

请在说明书指导下使用;
请勿大力按压开关按钮;
请勿自行拆机;
首次使用时请将电充满。



YT-N9C OSCILLATING DESK FAN USER'S MANUAL




Thank you for choosing ORICO.
Please read this manual carefully before using the product.

Introduction

Name: Auto Swing USB Desktop Fan
Model: N9C
Material: ABS, PP etc.

Specification

Size: 140x115x229mm
Input: DC5V, 1A
Voltage: DC3.7V
Charging time: about 4 hours




Description

- | | |
|-----------------------------|----------------------------|
| ① Fan blade | ⑤ Base |
| ② Front cover | ⑥ Working indication light |
| ③ Charging indication light | ⑦ Swing button |
| ④ ON/OFF Button | ⑧ USB-C port |

Guidance

- Press the button to switch the 1, 2, 3 and OFF mode. Press the button once, the fan will start working on mode 1, that is level 1 wind speed; press once more will be level 2 wind speed; press the button again will be level 3 wind speed. Press the button for the fourth time, it will be on OFF mode. Press the swing button when the fan on working mode, it will start auto-swing mode, press again it will stop swing.
- The fan can be adjusted by 30 degrees for ease of use as View-1.
- About charging.
Use a USB-C charger (5V) to charge. The charging light keep red light when charging process, and turn to green light when fully charged.
Tips: to ensure the battery life, please turn off the power supply and stop charging after the fan is fully charged.
- During working mode, the blue working indication light is always on. When changing gears, the indicator light of the corresponding gear follows the switching.



Warranty

This product is produced through rigorous quality control and inspection process, Six months warranty service is provided due to the product defects. For quality assurance, you can't get a free repair service even within the warranty period in the following cases.

- Due to careless user's fault.
- Natural disaster, water.
- Repair or arbitrary outside the designated Center for A/S apart.
- Shock, storage fault.
- Non-product issues other than the above items.

Warning

Please use the product under the instruction.
Do not press down the button with excessive force.
Do not disassemble the product.
Fully charge the product before first usage.

Made in China